


Turn All Power OFF BEFORE beginning Install



Begin by routing Blue, Black and Yellow Softstart wires into the electrical box. Then Crimp Disconnects on all softstart wire as indicated in Sofstart Drawing

Step 1) Follow White compressor wire from compressor to RUN capacitor "C" terminal, Disconnect and connet it to Blue Softstart wire.

Step 2) Connect Black Softstart wire to terminal White wire was on.

Step 3) Connect Yellow Softstart wire on a terminal next to Red compressor wire on "Herm" Side of RUN Capacitor.

Step 4) **IF** you see a **2nd red wire** next to red compressor wire diconnect and tape end . Drop it!

Step 5) Follow Blue compressor wire down approx 10" from top of compressor and "CUT" the wire.  
Crimp a female disconnect on end of Blue compressor wire attached to compressor, Connect to Brown Softstart wire.

Step 6) Crimp a male disconnect on other end of Blue compressor wire and Connect to Red Softstart wire.

**Secure All wires and tape connections**, Turn Power and AC breaker on, Turn Fan on Hi 1 min, Turn AC to Auto cool set Tstat to 55

Look at Softstart led Green light should be on ( Green light compressor is running), If green light on shut down replace all covers, Turn AC back on and run 30 min  
IF no green light enter Softstart Support Ticket for assistance